# LaserGas™ III SP Oxygen Analyzer





NEO Monitors LaserGas™ III SP oxygen analyzer (3<sup>rd</sup> generation) is specifically designed for service in hazardous areas. The analyzer consists of transmitter and receiver unit that are mounted diametrically opposite each other on stack, ducts or reactors. The laser will cross the process gas and concentration changes are detected in-situ and in real time. LaserGas™ III sets a new standard for fast and reliable Tunable Diode Laser Absorption Spectroscopy analysis (TDLAS). The laser scans the absorption line in milliseconds.

#### Features

- 3. Gen compact LaserGas™ electronics
- Explosion proof (Ex d), for use in Zone 1 and Class I/Division 2 areas
- · Fast response time
- Low power < 10 Watt</li>
- SIL2 capability
- No interference from other gases
- · Stable calibration, no zero drift
- · No gas sampling: In-situ measurement
- Safety application
- · Zero gas application
- No consumables
- · No purging of housing required
- Spectroscopy based measurements of the process gas temperature are possible

### **Applications**

- Safety application
- Chemical industry: inertisation control of reactors, Vinyl Chloride or PVC, Acryl Acid. Solvent acid, carbon black etc
- Petrochemical industry:
   FCC units, tail gas treament, flare gas monitoring, vent headers of incinerators, process heaters etc.
- Steel industry: Coke oven gas, converter coal gas, reheating furnaces
- and more

### Customer benefits

- In-situ monitoring
- · Highly reliable real time analyzer
- Low maintenance cost
- Reduce emission to the environment
- Easy to install and operate
- Reduce daily operation costs
- Optimize process
- Well proven measurement technique
- Less fuel consumptions
- · Reduced downtime

## LaserGas™ III SP Oxygen Analyzer

#### Technical Data

**Specifications** 

Detection limit (O<sub>2</sub>):

100 ppm \*\*

Max. process

gas temprature:

1600 °C

Max. process

gas pressure:

10 barA

Optical path length: 0,5 - 30 m

Repeatability:

1% of range (gas & application specific)

**Environmental conditions** 

Operating temperature:

ATEX: -40 °C to +65 °C

CSA: -40 °C to +60 °C

Storage temperature:  $-40 \,^{\circ}\text{C}$  to  $+70 \,^{\circ}\text{C}$ 

Protection classification: IP65

Inputs / Outputs

Analog output (3):

4 - 20 mA current loop (concentration and

transmission) 10/100 Base T

Digital output:

Ethernet (Modbus

TCP)

Relay output:

High gas, warning/ fault (normally clo-

sed)

Analog input: 4 - 20 mA process

temperature and pressure reading

Ratings

Power supply:

18-32 VDC

CSA rating:

Class 2 supply

Power consumption: Max. 20 W

4 - 20 mA output:

500 Ohm max. load impedance, not

isolated

Relay output: 1 A at 30 VDC

**Safety** 

Laser class:

Class 1M according to IEC 60825-1, eye safe

CE: Certified

EMC: Conformant with

directive 2014/30/EU

**Approvals** 

ATEX zone 1: Ex db [op is Ga] IIC T4

Gb

Ex tb [op is Da] IIIC

T100°C Db

CSA: Class I Div. 2,

Groups B, C and D

ATEX rating

connection box: II 2 GD Ex e IIC T5 Gb

-40°C ≤Ta≤65°C

Functional safety: IEC 61508 certified

SIL2 capability

**Installation and Operation** 

Flange dimension: DN50/PN10 or

ANSI 2"/150 lbs (other dimensions on

request)

Alignment tolerances: Flanges parallel within

1.5°

Purging of windows: Dry and oil-free

pressurised air or

nitrogen.

Purge flow:

10-50 l/min (application

dependent)

Calibration:

Check recommended

every 12 months

Maintenance

Calibration: Check recommended

every 12 months

Dimension and weight

Transmitter and recevier

unit (TU/RU):

215 mm (length, add

50 mm for purge unit) x 125 mm (diameter),

3,5 kg each

Window unit (optional): Wu 60 (length)

Wu 100 (length)

TU/RU connection box: 260 mm x 160 mm x

90 mm, 2,5kg

\*\*NOTE: Detection limits are specified as the 95% confidence interval for 1 m optical path and gas temperature / pressure =  $25^{\circ}$ C / 1 barA.

Measured in N<sub>2</sub>.

Your local distributor:



<sup>\*</sup> NEO Monitors reserve the right to change specifications without prior notice